

Not for Reproduction

REPAIR PARTS MANUAL
MODEL NO. ST1942 (96044001500)
LAWN TRACTOR



HOW TO USE THIS MANUAL

This manual is designed to provide the customer with a means to identify the parts on his/her tractor when ordering repair parts. The illustrations may or may not represent the actual assemblies; therefore, it is not recommended to use this manual as a guide to assemble or disassemble the tractor. Some hardware and parts are drawn larger in order to more readily identify them.

Each tractor has its own model number.

The model number for your tractor can be found on the fender under the seat.

Support / Help

If you require assistance or have questions concerning the application, operation, maintenance or parts for your product:

- Call Us Toll Free: 1-800-487-5951

When ordering parts, always give the following information:


- Product - "TRACTOR"
- MODEL NUMBER - "ST1942 (96044001500)"
- Part Number
- Part Description

TABLE OF CONTENTS


SCHEMATIC	3
ELECTRICAL.....	4-5
CHASSIS	6-7
DRIVE.....	8-9
ENGINE.....	10-11
STEERING	12-13
MOWER DECK	14-15
MOWER LIFT.....	16-17
SEAT	18-19
DECALS.....	20-21
WARRANTY.....	23

**TRACTOR - - MODEL NO. ST1942 (96044001500), PRODUCT NO. 960 44 00-15
SCHEMATIC 38**

SCH11





NOTE
YOUR TRACTOR IS EQUIPPED WITH A SPECIAL ALTERNATOR SYSTEM. THE LIGHTS ARE NOT CONNECTED TO THE BATTERY, BUT HAVE THEIR OWN ELECTRICAL SOURCE. BECAUSE OF THIS, THE BRIGHTNESS OF THE LIGHTS WILL CHANGE WITH ENGINE SPEED. AT IDLE THE LIGHTS WILL DIM. AS THE ENGINE IS SPEEDED UP, THE LIGHTS WILL BECOME THEIR BRIGHTEST.




IGNITION SWITCH

POSITION	CIRCUIT	"MAKE"
OFF	M+G+A1	
RUN/OVERRIDE	B+A1	
RUN	B+A1	L+A2
START	B + S + A1	



WIRING INSULATED CLIPS
NOTE: IF WIRING INSULATED CLIPS WERE REMOVED FOR SERVICING OF UNIT, THEY SHOULD BE RE-INSTALLED TO PROPERLY SECURE YOUR WIRING.





**TRACTOR - - MODEL NO. ST1942 (96044001500), PRODUCT NO. 960 44 00-15
ELECTRICAL 32**

ITEM NO.	MFG. NO.	B&S PART NO.	DESCRIPTION
1	532 16 34-65	80007564	Battery
2	874 76 04-12	80007922	Bolt Hex Head 1/4-20 x 3/4
8	587 20 51-01	80017590	Box Battery
16	532 17 61-38	80007576	Switch Interlock Push-In
21	585 44 74-01		Harness Socket Light w/4152J
22	532 00 41-52	80007511	Bulb Light
24	585 55 56-01	80007730	Cable Battery
25	585 55 55-01		Cable Starter
26	532 17 51-58	80007573	Fuse
27	873 51 04-00	80007906	Nut Keps Hex 1/4-20 unc
28	532 41 65-88	80009619	Cable, Ground
29	532 40 15-45	80007738	Switch, Seat
30	532 19 33-50	80007606	Switch, Ignition
33	532 41 19-33	80007777	Key/Chain
34	532 11 07-12	80007520	Switch Light/Reset
40	501 13 30-01		Harness Ignition Dash
41	817 72 04-08	80007891	Screw Thd Cut 1/4-20 x 1/2
42	532 13 15-63	80007546	Cover, Terminal
43	582 04 28-01		Solenoid
46	586 16 18-01	80017602	Gauge SRVCMNDR HRMTR
55	817 06 05-12	80007885	Screw Thdrol 5/16-18 x 3/4 TYTT
71	532 19 42-76		Harness Ignition Chassis
79	532 17 52-42	80007575	Socket Asm Bulb Twistlock
87	532 19 78-02	80007709	Switch Interlock Clutch Cable
90	532 43 53-95	80007806	Cover Terminal Battery
99	817 67 04-12	80007890	Screw 1/4-20 x 3/4
100	819 09 14-16	80007892	Washer 9/32 x 7/8 x 16
102	532 40 44-54	80007753	Harness Pigtail
105	532 40 75-68	80007770	Switch Reverse

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

**TRACTOR - - MODEL NO. ST1942 (96044001500), PRODUCT NO. 960 44 00-15
CHASSIS AND ENCLOSURES 39**


ITEM NO.	MFG. NO.	B&S PART NO.	DESCRIPTION
5	532 43 27-79	80007802	Dash
14	585 73 83-04	80007863	Hood
15	585 44 70-01	80007845	Lens Grille LH
18	585 44 69-01	80007844	Grille
25	585 44 71-01	80007846	Lens Grille RH
34	580 91 08-01	80007821	Plate Engine
36	817 06 05-12	80007885	Screw 5/16-18 x 3/4
37	585 88 74-01	80007866	Fender
52	873 68 05-00	80007908	Nut Crownlock 5/16-18
68	539 99 08-58		Screw THDROL 5/16-18 x 1/2
125	581 68 48-01	80007836	Clip Fuel Line
130	532 41 63-58	80007785	Screw #10 x 0.750 BOS Thread
137	532 18 49-21	80007580	Bumper Hood
138	532 43 97-47	80007809	Cupholder
146	581 85 79-01	80007838	Bolt
150	585 23 80-02		Duct Top Vent
151	532 40 78-07	80007771	Bracket Pivot
152	532 19 95-35	80007724	Shield Browning/Debris
159	817 00 06-12	80007883	Screw 3/8-16 x 3/4
161	532 44 00-29	80007810	Window Fuel
162	532 14 24-32	80007556	Screw Hex Wsh Hi-Lo 1/4 x 1/2 unc
165	532 19 68-26	80007684	Support Tank Rear
175	532 19 32-43	80007605	Crossmember
176	532 40 07-76	80007732	Screw 10-24 x 5/8 Wshd Qdrx
177	532 19 52-28	80007656	Bushing Steering
180	532 19 54-57	80007659	Chassis
181	532 43 97-46	80009618	Bushing Mtg. Fender Crgo.
182	532 19 30-57	80007602	Dash Lower
183	874 52 05-20	80007920	Bolt Full Thd 5/16-18 x 1-1/4
189	817 00 05-12	80007882	Screw 5/16-18 x 3/4
191	585 44 73-01	80007850	Insert Lens Reflective RH
194	873 90 05-00	80007911	Nut Lock Hex Flange 5/16-18
196	532 44 86-43	80007818	Console Asm. Deck Lift
198	532 44 15-52	80007813	Indicator Deck Lift
199	532 41 34-85	80007779	Plate Deck Lift
213	539 97 69-34		Bolt 5/16-18 x 3/4 Gr. 5 ZD
217	532 40 91-67	80007773	Rod Pivot Hood
218	532 19 63-95	80007664	X-Piece Hood Stop
228	532 19 51-61	80007653	Stud Fastener
235	532 40 61-29	80007766	Spacer Fender
236	873 93 05-00	80007915	Nut Center Lock 5/16-18 unc
287	817 60 04-06	80007889	Screw 1/4-20 x 3/8
297	585 44 72-01	80007847	Insert Lens Reflective LH
306	873 90 06-00	80007913	Nut Lock

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

**TRACTOR - - MODEL NO. ST1942 (96044001500), PRODUCT NO. 960 44 00-15
DRIVE 40**

ITEM NO.	MFG. NO.	B&S PART NO.	DESCRIPTION
1	- - - - -	- - - - -	Transaxle, TUFFTORQ K46 BT (426120) (Order parts from transaxle manufacturer.)
2	532 12 35-83	80007525	Key
15	819 13 13-16	80007896	Washer 13/32 x 13/16 x 16 Ga.
17	532 41 36-78	80007781	Spring Brake
26	532 19 96-79	80007725	Spring Return Cruise
29	532 40 38-06	80007752	Rod, Brake
33	812 00 00-01	80007879	Ring E
35	590 52 76-02		Rod Brake Park
37	532 18 89-67	80007590	Washer Hardened
42	532 12 48-72	80007539	Cover Foot Pedal
49	872 11 06-14	80007901	Bolt
50	532 19 43-27	80007645	Pulley Idler Flat
51	873 90 06-00	80007913	Lock Nut 3/8-16
52	532 19 43-26	80007644	Idler V-Groove
56	532 13 09-69	80007544	V-Belt Drive
64	532 19 78-65	80007710	Shaft Asm. Pedal Brake Control
73	874 49 05-40	80007919	Bolt 5/16-18 x 2-1/2 Gr. 5
92	874 76 05-20	80007924	Bolt 5/16-18 unc x 1.25
99	532 41 57-42	80007784	Rod Bypass
116	873 90 05-00	80007911	Nut Lock Hex Flange 5/16-18
125	817 00 05-12	80007882	Screw 5/16-18 x 3/4
143	539 99 08-58		Screw 5/16-18 x 1/2
153	532 12 47-88	80007527	Retainer Spring
159	876 02 04-12	80007926	Pin Cotter 1/8 x 3/4
160	532 16 94-84	80007566	Retainer Clip
161	532 10 57-09	80007516	Spring Return Clutch
163	532 44 82-75	80007816	Rod Control Pedal
166	532 42 91-64	80007797	Nut Push
167	532 40 52-57	80007759	Latch Brake Parking
170	532 19 43-22	80007613	Keeper Belt Centerspan
171	872 11 06-16	80007902	Bolt RDHD SQNK 3/8-16 unc x 2
183	532 13 70-57	80007547	Spacer Split
184	532 40 96-30	80017588	Handle Parking Brake
185	872 11 06-22	80007903	Bolt Rdhd Sqnk 3/8-16 x 2-3/4 Gr. 5
186	532 19 43-21	80007612	Spacer Retainer
187	819 13 32-10	80007895	Washer
188	582 21 70-01	80007643	Link Clutch Ground Drive, Long
189	532 19 43-17	80007610	Bellcrank Ground Drive
190	532 19 43-18	80007611	Keeper Bellcrank Ground Drive
205	532 12 17-48	80007522	Washer
206	532 44 85-96	80007817	Bracket Mount Latch
207	587 03 14-01	80017593	Latch Control
208	532 19 78-69	80007712	Gear Sector Control
209	532 40 07-69	80007731	Rod Control Cruise
210	532 40 09-80	80007734	Rocker Asm. Pedal
211	532 12 01-83	80007521	Bushing Brake Shaft
213	532 42 47-44	80007795	Knob Control Cruise
214	532 42 12-63	80007788	Pedal Forward
215	532 40 17-23	80007740	Pedal Reverse
216	532 19 61-31	80007661	Bracket Pulley Idler
222	879 21 20-10	80007927	Washer 21/32 x1-1/4 10 Ga.
225	532 40 33-19	80007751	Keeper Belt Trans.
227	817 49 05-12	80007888	Screw 5/16-18 x 3/4
325	585 66 85-02	80012744	Torque Strap
326	585 67 08-02	80012745	Bracket Trq
336	587 25 96-01	80012743	Bolt

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm



engine-tex_BS_151

**TRACTOR - - MODEL NO. ST1942 (96044001500), PRODUCT NO. 960 44 00-15
ENGINE 24**

KEY NO.	PART NO.	DESCRIPTION
1	-----	Engine B&S Model No. 33R877-0024-G1 (501516501)(Order Parts From Engine Manufacturer.)
2	590 64 53-01	Muffler
9	501 83 26-02	Keeper Belt Engine
12	586 47 85-01	Pulley Engine
15	532 43 80-26	Tank Fuel
18	585 12 48-02	Cap Fuel
20	532 18 38-97	Control Throttle/Choke
21	532 41 63-58	Screw #10 X 0.750 Bos Thread
28	532 40 11-35	Line Fuel 64" Rear Emis. Ca Lp
29	532 13 71-80	Kit Spark Arrestor
37	532 12 34-87	Clamp Hose Blk.
42	539 99 02-47	Washer Lock SLW STD 7/16
45	873 51 04-00	Nut, Keps Hex 1/4-20 unc
69	532 16 52-91	Gasket
79	532 19 23-34	Screw Socket Hd 5/16-18 X .75
81	532 14 84-56	Tube Drain Oil Easy
82	532 42 82-87	Valve Oil Drain
84	817 06 06-20	Screw 3/8-16 x 1-1/4
85	501 60 65-01	Bolt Hex 7/16-20 x 4 x Gr. 5-1.5
87	532 17 18-77	Bolt 5/16-18 unc x 3/4 w/Sems Blk
90	817 00 06-16	Screw 3/8-16 x 1 Smgml Tap/R Blk
94	581 88 09-01	Tube Exhaust

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

For engine service and replacement parts, call the toll free number for your engine manufacturer listed below:

Briggs & Stratton 1-800-233-3723

Engine Power Rating Information

The gross power rating for individual gas engine models is labeled in accordance with SAE (Society of Automotive Engineers) code J1940 (Small Engine Power & Torque Rating Procedure), and rating performance has been obtained and corrected in accordance with SAE J1995 (Revision 2002-05). Torque values are derived at 3060 RPM; horsepower values are derived at 3600 RPM. Actual gross engine power will be lower and is affected by, among other things, ambient operating conditions and engine-to-engine variability. Given both the wide array of products on which engines are placed and the variety of environmental issues applicable to operating the equipment, the gas engine will not develop the rated gross power when used in a given piece of power equipment (actual "on-site" or net power). This difference is due to a variety of factors including, but not limited to, accessories (air cleaner, exhaust, charging, cooling, carburetor, fuel pump, etc.), application limitations, ambient operating conditions (temperature, humidity, altitude), and engine-to-engine variability. Due to manufacturing and capacity limitations, Briggs & Stratton may substitute an engine of higher rated power for this Series engine.

**TRACTOR - - MODEL NO. ST1942 (96044001500), PRODUCT NO. 960 44 00-15
STEERING ASSEMBLY 41**

ITEM NO.	MFG. NO.	B&S PART NO.	DESCRIPTION
1	532 42 41-46	80007793	Wheel, Steering
2	532 19 59-68	80007660	Axle Asm., Front
4	532 40 30-87	80007746	Spindle Asm., LH
5	532 40 30-88	80007747	Spindle Asm., RH
6	532 12 49-31	80007541	Bearing, Race Thrust Harden
7	532 12 17-48	80007522	Washer 25/32 x 1-5/8 x 16 Ga.
8	812 00 00-29	80007880	Ring, Clip #T5304-75
9	585 88 79-01	80007867	Cap, Spindle
13	532 12 17-49	80007523	Washer 25/32 x 1-1/4 x 16 Ga.
14	539 99 01-18		Washer, SLW ZD 3/8
15	873 54 06-00	80007907	Nut, Crown Lock 3/8-24 unf
16	587 01 60-02	80013673	Steering Shaft
19	532 19 47-29	80007646	Plate Steering
20	532 43 27-84	80007803	Boot, Steering
21	586 84 02-01	80013674	Adapter Wheel Steering
22	585 02 98-02	80013675	Bearing
26	532 42 46-91	80007794	Insert, Wheel Steering
27	819 21 16-16	80013676	Washer
28	817 00 06-12	80007883	Screw 3/8-16 x 3/4
35	532 19 47-32	80007647	Gear, Sector Plate
45	587 01 64-01	80013677	Washer 3/8 ID 2-3/8 OD 12 Ga. PLTD
50	873 90 06-00	80007913	Nut Lock Flg 3/8-16 unc
53	532 18 89-67	80007590	Washer Hardened .793 x 1.637 x .060
57	532 40 74-65	80007769	Bracket Upstop
58	532 19 47-47	80007651	Bolt Shoulder Sector Pivot CFM
59	532 19 47-48	80007652	Washer Thrust Sector Steering
60	873 97 10-00	80007918	Nut Flange Lock 5/8-11
61	532 19 47-40	80007649	Draglink, LH
62	532 19 47-41	80007650	Draglink, RH
63	817 00 05-12	80007882	Screw 5/16-18 x 3/4
64	532 19 98-49	80007727	Retainer Clip Spring Steering
66	871 02 07-48	80007899	Bolt Hex Fghd 7/16-14 x 3 Serr
67	532 19 47-37	80007648	Bushing PM Front Axle
68	873 90 07-00	80007914	Nut Lock Flange 7/16-14 Gr. 5
69	532 19 91-62	80007720	Washer 1.5 x .505 x .118
70	585 33 88-01	80017595	Bracket Deck Susp. Front
75	580 68 37-01	80013678	Pinion
76	580 68 36-01	80013679	Screw Head Sock
122	532 44 49-62	80007814	Cap Gear Sector


NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

**TRACTOR - - MODEL NO. ST1942 (96044001500), PRODUCT NO. 960 44 00-15
MOWER DECK 44**

ITEM NO.	MFG. NO.	B&S PART NO.	DESCRIPTION	ITEM NO.	MFG. NO.	B&S PART NO.	DESCRIPTION
1	585 84 54-01		Mower Housing	68	532 42 96-36		V-Belt
2	539 99 03-16		RHDNB 5/16-18 x 3/4 Gr. 5 ZD	69	872 14 05-05		Bolt RDHD 5/16-18 x 5/8
6	532 19 51-86	80007655	Arm Suspension	70	532 19 97-79	80007726	Clutch Asm. Manual
7	532 41 63-58	80007785	Screw #10 x 0.750 BOS Thread	111	532 40 47-84		Bracket Wheel Gauge LH
11	532 13 89-71		Blade Mower Hi-Lift	112	532 40 47-85		Bracket Wheel Gauge RH
12	584 30 93-01	80017598	Screw 7/16-20 x 1 Hx Hd	113	817 00 05-10	80007881	Screw 5/16-18
13	587 25 65-01	80018702	Shaft Assembly, Mandrel	116	532 12 48-42	80007528	Bolt, Shoulder
14	532 18 72-81	80007583	Housing, Mandrel	117	589 52 74-01		Wheel, Gauge
15	585 32 39-01	80018703	Bearing, Mandrel	119	819 12 14-14	80007893	Washer 13/32 x 7/8 x 14 Ga.
19	532 19 65-39	80007665	Bolt, Shoulder	122	532 19 72-58	80007690	Keeper Belt Eng. LH
20	532 15 97-70		Baffle Vortex	123	532 19 72-59	80007691	Keeper Belt Eng. RH
21	873 68 05-00	80007908	Nut	144	532 19 92-04	80007721	Keeper Belt
23	532 19 25-57	80007596	Bracket, Deflector	145	532 19 31-97	80007603	Pulley Idler Primary
24	532 10 53-04	80007515	Cap, Sleeve	147	532 40 19-71		Spring Return
25	532 19 70-26	80007686	Spring, Torsion, Deflector	152	584 24 35-01	80007842	Cable Clutch Manual w/Spr.
26	532 11 04-52	80007518	Nut, Push	188	532 19 51-61	80007653	Stud Fastener
27	532 40 30-04	80009620	Shield, Deflector	189	873 90 05-00	80007911	Nut Lock Hex Flange
29	532 13 14-91	80007545	Rod, Hinge	192	532 19 72-60		Bracket Brake Stand LH
32	532 19 74-73	80007695	Pulley, Mandrel	195	817 00 06-12	80007883	Screw 3/8-16 x 3/4
33	532 40 02-34	80007729	Nut, Toplock, Flanged	241	532 15 29-27	80007562	Screw
34	872 11 06-12	80007900	Bolt Carr Sh. 3/8-16 x 1-1/2 Gr. 5	242	532 41 55-98	80007783	Washout Port
36	532 19 73-79	80007694	Pulley, Idler	254	585 31 68-05		Plate Reinf Front
37	819 13 13-16	80007896	Washer 13/32 x 13/16 x 16 Ga.	255	585 31 70-05		Plate Reinf Side
38	589 67 61-02		Keeper Belt Mandrel	256	592 80 78-01		Bolt 1/4-20 x 3/4 ZN
40	873 90 06-00	80007913	Nut, Lock Flg. 3/8-16 unc	257	873 90 04-00		Short Neck
41	584 95 39-01	80017599	Bolt .313-18 x1.19	--	587 25 33-01	80017597	Nut Hex Flange
42	532 19 84-10	80007714	Spring Torsion Brake				Mandrel Assembly (Includes housing (Key #14), shaft assembly (Key #13), and bearing (Key #15) only - pulley/nut/washer and blade bolt/washers not included)
43	532 19 72-56	80007689	Spring Torsion Retainer				Quick Connect Coupling
46	532 13 77-29	80007549	Screw	--	532 41 64-05	80007786	Replacement Mower, Complete
47	532 19 72-50	80007688	Bracket Clutch Cable				
55	532 43 71-10	80007687	Arm, Idler				
56	532 19 90-92	80007715	Spacer, Retainer				
57	817 00 06-16	80007884	Screw Hexwsh Thd 3/8-16 x 1				
59	532 14 10-43	80007555	Guard, Tuv Idler (94)				
60	532 19 72-61		Arm Brake Mower				
62	872 11 06-16		Bolt RD HD SQNK 3/8-16 unc x 2				
63	532 19 94-77	80007723	Arm Brake Mower				
64	532 19 99-18		Linkage Brake				
67	532 40 30-12	80007745	Handle, Clutch Cable				

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR - - MODEL NO. ST1942 (96044001500), PRODUCT NO. 960 44 00-15
MOWER LIFT **45**



lift-tex_47

*Key 91 may be substituted for Key 101


**TRACTOR - - MODEL NO. ST1942 (96044001500), PRODUCT NO. 960 44 00-15
MOWER LIFT 45**

ITEM NO.	MFG. NO.	B&S PART NO.	DESCRIPTION
2	532 42 20-27	80007791	Shaft Asm., Lift
3	532 19 52-31	80007657	Lever Asm., Lift RH
7	580 96 23-01	80007822	Grip, Lever
10	532 19 63-14	80007663	Spring Torsion
87	532 19 42-09	80007608	Pin Cotter 7/16 Bow Tie Lock
88	532 41 07-10	80007776	Spring Lift Assist
89	819 19 19-12	80007898	Washer Clear Zinc
90	532 19 42-08	80007607	Pin Cotter 5/16 Bow Tie Lock
91	532 19 51-81	80007654	Link Asm. Lift Rear
97	817 00 06-12	80007883	Screw 3/8-16 x .75 Smgml Tap/R.Z
98	532 19 52-70	80007658	Link Lift Susp. Front Mower
100	873 93 06-00	80007916	Nut Centerlock 3/8-16 unc
101	532 40 70-03	80007768	Link Asm. Lift Fixed
116	819 15 15-16	80017589	Washer 15/32 x 15/16 x 16 Ga.

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

Not For Reproduction

TRACTOR - - MODEL NO. ST1942 (96044001500), PRODUCT NO. 960 44 00-15
SEAT ASSEMBLY **42**




seat-tex_6.5SL_15

**TRACTOR - - MODEL NO. ST1942 (96044001500), PRODUCT NO. 960 44 00-15
SEAT ASSEMBLY 42**


ITEM NO.	MFG. NO.	B&S PART NO.	DESCRIPTION
1	532 40 66-25	80007767	Seat
2	532 18 01-66	80007577	Bracket Pivot Fender
6	873 80 06-00	80007910	Nut, Lock w/lns. 3/8-16 unc
7	589 48 35-01		Spring, Seat Cprsn
8	532 17 18-77	80007568	Bolt 5/16-18 unc x 3/4 w/Sems
10	587 23 20-02		Pan, Seat
21	587 90 78-01	80017607	Bolt, Shoulder 5/16-18 x 5/8
37	873 80 05-00	80007909	Nut, Lock 5/16-18 unc
40	532 19 76-61	80007696	Handle Slide Seat
41	532 19 82-00	80007713	Spring Latch Seat
43	874 76 06-12	80007925	Bolt Fin Hex 3/8-16 unc x 3/4
44	501 05 18-01		Washer Winged
46	588 09 04-01		Bolt 3/8-16 x 1, 1.25 OD Wsh SEMS

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

Not for Reproduction



WHEELS AND TIRES



**TRACTOR - - MODEL NO. ST1942 (96044001500), PRODUCT NO. 960 44 00-15
DECALS 27**

ITEM NO.	MFG. NO.	B&S PART NO.	DESCRIPTION
1	585 57 12-01	80007859	Decal, Hood RH/LH
2	584 90 46-01	80008517	Decal, Keep Hand Away
3	596 47 32-01		Decal, Side Panel
4	592 90 35-01		Decal, Fender
5	585 55 61-01		Decal, Eng H.P.
6	581 57 89-01	80007831	Decal, Fender Operator's
7	586 11 20-01	80009616	Decal, SDFNDR RH/LH
8	592 83 87-01		Decal, UPD Barcode
9	596 47 33-01		Decal, Deck 42 inch
13	585 57 13-01	80007860	Decal, Steering Wheel
11	581 50 34-01		Decal, Replacement
14	581 58 00-01	80007834	Decal, Mower Schematic
--	532 40 95-07	80007775	Pad, Footrest RH
--	532 40 95-05	80007774	Pad, Footrest, LH
--	586 11 75-24	80009617	Quick Start Guide
--	581 72 48-01	80007837	Decal, Bypass
--	114 06 39-49		Manual, Operator's (English/Spanish)

ITEM NO.	MFG. NO.	B&S PART NO.	DESCRIPTION
1	532 05 91-92	80007512	Cap, Valve, Tire
2	532 06 51-39	80007514	Stem, Valve
3	532 13 83-36	80007550	Rim Assembly, Front
4	532 05 99-04	80007513	Tube, Front
5	532 10 62-22	80007517	Tire, Front 15 x 6-6
6	532 12 49-57	80007542	Fitting, Grease
7	532 12 49-59	80007543	Bearing, Flange
8	532 17 50-39	80007572	Cap, Axle (Front Wheel Only)
9	532 13 84-68	80007552	Tire, Rear 20 x 8-8
10	532 12 49-26	80007540	Tube, Rear
11	532 13 83-37	80007551	Rim Assembly, Rear
--	532 14 43-34	80007557	Sealant, Tire (10 oz. Tube)

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

SERVICE NOTES

Not for Reproduction

LIMITED WARRANTY

The Manufacturer warrants to the original consumer purchaser that this product as manufactured is free from defects in materials and workmanship. For a period of three (3) years from date of purchase by the original consumer purchaser, we will repair or replace, at our option, without charge for parts or labor incurred in replacing parts, any part which we find to be defective due to materials or workmanship. This Warranty is subject to the following limitations and exclusions.

1. This warranty does not apply to the engine, transaxle/transmission components, battery (except as noted below) or components parts thereof. Please refer to the applicable manufacturer's warranty on these items.
2. Transportation charges for the movement of any power equipment unit or attachment are the responsibility of the purchaser. Transportation charges for any parts submitted for replacement under this warranty must be paid by the purchaser unless such return is requested by the manufacturer.
3. Battery Warranty: On products equipped with a Battery, we will replace, without charge to you, any battery which we find to be defective in manufacture, during the first ninety (90) days of ownership. After ninety (90) days, we will exchange the Battery, charging you 1/12 of the price of a new Battery for each full month from the date of the original sale. Battery must be maintained in accordance with the instructions furnished.
4. The Warranty period for any products used for rental or commercial purposes is limited to 90 days from the date of original purchase.
5. This Warranty applies only to products which have been properly assembled, adjusted, operated, and maintained in accordance with the instructions furnished. This Warranty does not apply to any product which has been subjected to alteration, misuse, abuse, improper assembly or installation, delivery damage, or to normal wear of the product.
6. Exclusions: Excluded from this Warranty are belts, blades, blade adapters, normal wear, normal adjustments, standard hardware and normal maintenance.
7. In the event you have a claim under this Warranty, you must return the product to an authorized service dealer.

Should you have any unanswered questions concerning this Warranty, please contact:

Visit us at www.snapper.com
Call a Customer Support Representative at 800-317-7833
Briggs & Stratton Power Products Group, LLC
12301 W. Wirth St., Wauwatosa, WI 53222

giving the model number, serial number and date of purchase of your product and the name and address of the authorized dealer from whom it was purchased.

THIS WARRANTY DOES NOT APPLY TO INCIDENTAL OR CONSEQUENTIAL DAMAGES AND ANY IMPLIED WARRANTIES ARE LIMITED TO THE SAME TIME PERIODS STATED HEREIN FOR OUR EXPRESSED WARRANTIES. Some areas do not allow the limitation of consequential damages or limitations of how long an implied Warranty may last, so the above limitations or exclusions may not apply to you. This Warranty gives you specific legal rights, and you may have other rights which vary from locale to locale.

This is a limited Warranty within the meaning of that term as defined in the Magnuson-Moss Act of 1975.

Not for Reproduction

