




Product Description: Chain Saw
Model Number: CS1400
Body Number: 0890017003_S
Version: A
Issue Date: 2021/12/10



Service Part List_CS1400_Version A

No.	Product Model#	Part Number	Description	Qty
1	CS1400	3127500001	Sheath	1
2	CS1400	3127504002	Front Handle	1
3	CS1400	5610042014	Tapping Screw	33
4	CS1400	3127496001	Switch Trigger	1
5	CS1400	3127495001	Lock off Button	1
6	CS1400	3660427002	Spring	1
7	CS1400	2825243001	Motor Assembly	1
8	CS1400	3127518001	Board	1
9	CS1400	5610011006	Tapping Screw	9
10	CS1400	3700894001	Cord Anchorage	2
11	CS1400	2823856001	Transmission ASSY	1
12	CS1400	2823167001	Screw ASSY	1
13	CS1400	3421169001	Cover	1
14	CS1400	2823860001	Cover ASSY	1
15	CS1400	5660028001	E Ring	1
16	CS1400	5660208001	Gasket	1
17	CS1400	3421564001	Sprocket	1
18	CS1400	5650042001	Plain Washer	2
19	CS1400	3127510001	Gear	1
20	CS1400	5670185001	Pin	1
21	CS1400	3127507001	Support	1
22	CS1400	3660013003	Spring1	1
23	CS1400	3127497001	Power Pack Button	1
24	CS1400	3127498001	Power Pack Button	1
25	CS1400	2824708001	Cover Assembly	1
201	CS1400	2823933002	Kettle ASSY	1