

POWERED BY

# DUCAR

PROPULSÉ PAR

## Parts diagram




The model may differ slightly from the picture

# DUESB726

## 26" Snowblower

# CHUTE




	<b>Part number</b>	<b>Part name</b>	<b>Quantity</b>
<b>1</b>	DUPKC42A-03A-1A	Chute welded	1
<b>2</b>	DUPKC55-03-17	Handle spring	1
<b>3</b>	DUPKC30A-05-2	Chute spring	1
<b>4</b>	DUPKC30A-05-4	Chute wire	1
<b>5</b>		Nylon cable ties 2.5 X 150	1
<b>6</b>	DUPKC30A-05-3	Support pole	1
<b>7</b>	DUPKC42A-03-2	Big sealing pad	1
<b>8</b>	DUPKC30A-05-6	Lower hinge	1
<b>9</b>	DUPKC30A-05-7	Hinge shaft	1
<b>10</b>	DUPGB/T12618-1990	Rivet 4x10	7
<b>11</b>	DUPKC30A-05-08	Upper hinge	1
<b>12</b>	DUPKC42A-03-3A	Deflector welded	1
<b>13</b>	DUPKC21-23	Washer	1
<b>14</b>	DUPKC42A-03-4	Safety rod	1
<b>15</b>	DUPKC55-26	Plastic washer	1
<b>16</b>	DUPGB/T91-2000216	Split pin 2X16	1



# SNOWBLOWER ASSEMBLY

	<b>Part number</b>	<b>Part name</b>	<b>Quantity</b>
<b>17</b>	GB/T95-2002	flat washer 8	4
<b>18</b>	DUPJB/T7940.1-1995	Oil cup M8x1	2
<b>19</b>	DUPKCA34-01-03	Grease cap	2
<b>20</b>	DUPKCA34-01-04	Safety pin	2
<b>21</b>	DUPKCA34-01-05	Gearbox	1
<b>22</b>	GB/T889.1-2000-6	jam nut M6	4
<b>23</b>	GB/T93-1987-6	spring washer 6	4
<b>24</b>	DUPKCA34-01-06	Impeller	1
<b>25</b>	GB/T5782-200040	bolt M6x40	2
<b>26</b>	GB/T5782-200030	bolt M6x30	2
<b>27</b>	DUPKCA34-01-07R	Support right	1
<b>28</b>	DUPKCA34-01-07L	Support left	1
<b>29</b>	DUPKCA26-01-03	Auger, left	1
<b>30</b>	GB/T93-1987-8	spring washer 8	2
<b>31</b>	DUPGB/T12-1988	bolt M8x20	2
<b>32</b>	DUPGB/T12-1988	bolt M8x20	4
<b>33</b>	GB/T12-1988-25	bolt M8x25	4
<b>34</b>	GB/T845-1985-95	screw ST4.2x9.5-F	2
<b>35</b>	DUPKC55-01-21	Shovel support	1
<b>36</b>	DUPKC42-01-20	Bearing seat	2
<b>37</b>	DUPSB204	Bearing	1
<b>38</b>	DUP4LXP900	Impeller pulley	1
<b>39</b>	GB/T5287-2002	super washer 10	1
<b>40</b>	GB/T5780-2000-25	bolt M10x25	1
<b>41</b>	GB/T1095-2003	flat key A 6x20	1
<b>42</b>	DUPKCA34-01-14	Pad	3
<b>43</b>	DUPKCA34-01-15	Gear plate gasket	1
<b>44</b>	DUPKCA34-01-16	Gear plate	1
<b>45</b>	DUPKCA34-01-17	Gear plate cover	1
<b>46</b>	DUPKCA34-01-18	Gear plate outer cover	1
<b>47</b>	GB/T5780-2000-20	bolt M8*20	3
<b>48</b>	DUPKCA34-01-09	Plastic washer	2
<b>49</b>	DUPKCA34-01-11	Higher panel support, right (optional)	1
<b>50</b>	DUPKCA26-01-04	Higher panel(optional)	1
<b>51</b>	DUPKCA34-01-13	Higher panel support, left (optional)	1
<b>52</b>	GB/T12-1988-16	bolt M8x16 (optional)	4
<b>53</b>	GB/T6183.1-2000	jam nut M8 (optional)	4

# ENGINE-TRANSMISSION



	Part number	Part name	Quantity
1	GB/T9074.17-1988	Bolt M10x25	2
2	DUPKC90-02-21A	Handlebar	1
3	DUPKC55-02-25A	Handlebar spacer	2
4	GB/T9074.17-1988	Bolt M10x45	2
5	GB/T9074.17-1988	Bolt M6x12	8
6	DUPKC30A-02-30	Support rod	2
7	DUPKC30A-02-01	Cover 1	2
8	GB/T5780-2000	Bolt M6x20	1
9	DUPKC21-02-2	Bushing	1
10	DUPKCM24-02C-19	Pulley seat	1
11	GB/T9074.17-1988	Bolt M6X12	4
12	DUPKC21-02C-01	Short Throttle Cable	1


# ENGINE-TRANSMISSION

	<b>Part number</b>	<b>Part name</b>	<b>Quantity</b>
<b>13</b>	DUPKC40-28	Pulley	1
<b>14</b>	GB/T899.1-2000	Lock nut M6	1
<b>15</b>	GB/T9074.17-1988	Bolt M8X20	4
<b>16</b>	DUPKC30A-02-02	Connecting plate	1
<b>17</b>	DUPKC21-02C-03	Engine mount	1
<b>18</b>	GB/T5780-2000	Bolt M8X40	4
<b>19</b>	DIN6927	Lock nut M8	4
<b>20</b>	DUPSN420-A	Engine	1
<b>21</b>	DUP3LXP820	Belt	1
<b>22</b>	DUPKC30A-02-03	Drive wheel	1
<b>23</b>	DUP3LPX820	Belt pulley	1
<b>24</b>	GB/T5287-2002	Super washer 8	1
<b>25</b>	GB/T5786-2000	Bolt M8X1X30	1
<b>26</b>	DUPKC30A-02-04A	Transmission box assembly	1
<b>27</b>	GB/T9074.17-1988	Bolt M6X20	2
<b>28</b>	DUPKC30-02-12	Gear connector	1
<b>29</b>	DUPKC90-02-07	Plastic bushing	2
<b>30</b>	DUPKC55-02-05	Shift fork	1
<b>31</b>	GB/T9074.17-1988	Bolt M6X16	13
<b>32</b>	DUPKC30A-02-05	Bearing seat	2
<b>33</b>	DUPGB/T276-1997-1	Bearing 6200	4
<b>34</b>	DUPGB/T894.1-1986A	Circlip 25	1
<b>35</b>	DUPKC21-02-13	Shift shaft bearing	1
<b>36</b>	DUPKC21-02-12B	Pulley hub	1
<b>37</b>	DUPKC21-02-11B	Rubber wheel	1
<b>38</b>	DUPKC30A-02-06	Sleeve 15x20x15	2
<b>39</b>	DUPKC30A-02-07	Gear	1
<b>40</b>	DUPKC30A-02-09	Hexagon shaft	1
<b>41</b>	DUPKC30A-02-11	Small chain wheel	1
<b>42</b>	DUPKC30A-02-12	Sleeve 12x15x8	1
<b>43</b>	DUPKC30A-02-10-2	Transit axle	1
<b>44</b>	DUPKC30A-02-10-1	Wheel sprocket	1
<b>45</b>	DUPGB/T1243-1997	Chain 085-32	1
<b>46</b>	DUP16X4.80-8	16X4.80-8 tyre	2
<b>47</b>	DUPKC30A-02-13	Rim	2
<b>48</b>	GB/T9074.17-1988	Bolt M6x16	4
<b>49</b>	DUPKC90-02-11	Pillow block bearing	2
<b>50</b>	GB/T899.1-2000	Lock nut M8	6
<b>51</b>	DUPGB/T276-2013-2	Ball bearing 6205	2
<b>52</b>	DUPKC30A-02-14	Sleeve 25x34x16	1
<b>53</b>	DUPKC30B-02-02A	Sleeve	1
<b>54</b>	DUPKC90-03-07	Clip	2

# ENGINE-TRANSMISSION

	<b>Part number</b>	<b>Part name</b>	<b>Quantity</b>
<b>55</b>	DUPKC30B-02-03	Pin 6x40	1
<b>56</b>	GB/T1566-2003	Flat key 6x4x45	2
<b>57</b>	GB/T1095-2003	Flat key 8x7x22	1
<b>58</b>	GB/T879.2-2000	Cylindrical pin 8x30	2
<b>59</b>	DUPKC30A-02-21	Short shaft sleeve 25x34x6	2
<b>60</b>	GB/T5780-2000	Bolt M8x30	1
<b>61</b>	DUPKC55-02-21	Tension pulley	1
<b>62</b>	DUPKC30A-02A-4	Tension lever	1
<b>63</b>	GB/T12-1988	Bolt M8X45	1
<b>64</b>	DUPKC30A-02A-5	Tension arm	1
<b>65</b>	DUPKC55-01-24	Bushing	1
<b>66</b>	DUPKC55-01-27	Large tension pulley	1
<b>67</b>	DUPKC55-01-26	Cushion	1
<b>68</b>	DUPKC30A-02-31	Clutch lever	1
<b>69</b>	GB/T848-2002	Flat washer; 12	1
<b>70</b>	GB/T955-1987	Spring washer 12	1
<b>71</b>	DUPKC21-02C-09	Adapter block	1
<b>72</b>	DUPKC90-02-15	Spring	1
<b>73</b>	DUPKC30A-02-23	Friction disc support	1
<b>74</b>	DUPKC30A-02-24	Sleeve 13x20x20	1
<b>75</b>	GB/T9074.17-1988	Bolt M8X16	2
<b>76</b>	GB/T899.1-2000	Lock nut M12	1
<b>77</b>	DUPKC21-02C-12	Brake tension spring	1
<b>78</b>	GB/T 109-1986	Rivet 4x12	2
<b>79</b>	DUPKC30A-02-25	Brake pad	1
<b>80</b>	DUPKC21-02C-13	Pulley	1
<b>81</b>	GB/T9074.17-1988	Bolt M6x20	3
<b>82</b>	DUPKC90-02-12	Triangle flange bearing	2
<b>83</b>	GB/T276-1997	Ball bearing 6002	2
<b>84</b>	DUPKC30A-02-27	Bracket	1
<b>85</b>	DUPS03*00493	B Pin;1.5X25	1
<b>86</b>	DUPKC21-02C-17	Reset spring	1
<b>87</b>	DUPKC90-02-31	Support rod	1
<b>88</b>	DUPKC30A-02-26A	Bottom plate for transmission box	1

# HANDLES




	Part number	Part name	Quantity
1	DUPKC30-03C-01R	Upper handle, right	1
2	DUPKC30-03-02	Control panel	1
3	DUPGB/T899.1-2000	Nut M8	10
4	DUPKC30-03-44A	Handle bracket	2
5	DUPGB/T12-1988	Bolt M8*40	4
6	DUPGB/T5780-2000	Bolt M6X20	2
7	DUPKC21-02-2	Bushing	2
8	DUPKC40-28	Pulley	2
9	DUPKCA28-04-03	Block - clutch paddle	2
10	DUPGB/T12-1988	bolt M8X45	2
11	DUPKC30-03-49	Long wire	2
12	DUPGB/T12-1988	Bolt M8*35	2
13	DUPS03*00493	B pin 1,5 x 25	4
14	DUPKC30-03-09	Walking lever	1
15	DUPGB/T41-2000	Nut M10	2
16	DUPKC30-03-2(M4)	Gear handle	2

# HANDLES

	<b>Part number</b>	<b>Part name</b>	<b>Quantity</b>
<b>17</b>	DUPKC30-03-11GGP	Chute cap handle	1
<b>18</b>	DUPGB/T6183.1-2000	Spring-comp M6	
<b>19</b>	DUPKC30-03-45	Lever, control-shift	2
<b>20</b>	DUPKCA28-04-14	Short welded connecting rod	1
<b>21</b>	DUPKCA28-04-04	Left control handle	1
<b>22</b>	DUPKC55-03-15	Rubber washer	2
<b>23</b>	DUPGB/T5287-2002	Rod- interlock pivot	2
<b>24</b>	DUPGB/T 70.1-1985	Screw M8x150	1
<b>25</b>	DUPKCA28-04-17	Pin	1
<b>26</b>	DUPKC30-03-50	Cam right, interlock	2
<b>27</b>	DUPKCA28-04-16	Cam left, interlock	2
<b>28</b>	DUPKC55-03-11	Spring-comp	1
<b>29</b>	DUPGB/T 70.1-1985	Screw M8x60	1
<b>30</b>	DUPKCA28-04-08	Long welded connecting rod	1
<b>31</b>	DUPGB/T 12618-1990	Rivet 4x10	4
<b>32</b>	DUPKC90-04-04A	Heated handle	2
<b>33</b>	DUPKCA28-04-10	Left handle	1
<b>34</b>	DUPGB/T899.1-2000	Bolt M6	6
<b>35</b>	DUPKC55-03-05-6	Short sleeve	2
<b>36</b>	DUPKC30-03-14	Input wire	1
<b>37</b>	DUPSD3-2(P)21	Switch	2
<b>38</b>	DUPKC30A-05-4	Chute cap cable	1
<b>39</b>	DUPKCD26-06-2	Preset spring	1
<b>40</b>	DUPKC30-03-44A	Handle pulley seat	2
<b>41</b>	DUPKC30-03-32	Aluminum swivel assembly	1
<b>42</b>	DUPKC30-03-31	Rubber washer	10
<b>43</b>	DUPKC30-03-23	Lower rotate lever seat	1
<b>44</b>	DUPKC30-03C-01L	Upper handle, left	1
<b>45</b>	DUPKC30-03-22A	Soft shaft assembly	2
<b>46</b>	DUPGB/T 818-2000	Screw M6x10	2
<b>47</b>	DUPGB/T95-2002	Flat washer 6	2
<b>48</b>	DUPKC30-03-24	Panel	1
<b>49</b>	DUPGB/T9074.17-1988	Bolt M6x16	2
<b>50</b>	DUPKC30-03-26	Cover	1
<b>51</b>	DUPGB/T 889.1-2000	Lock nut M6	2
<b>52</b>	DUPKC21-03-15	LED Light Strip	1
<b>53</b>	DUPGB/T846-1985	Screw ST3.5X16F	2

# SNOWBLOWER ASSEMBLY



	Part number	Part name	Quantity
1	DUPDIN6927	Lock nut M8	6
2	DUPKC55-10	Right gimbal	1
3	DUPGB/T 6171-2000	nut M8x1	1
4	DUPKC26-04A	Gear connector bar	1
5	DUPGB/T 889.1-2000	nut M8	5
6	DUPS07*00447	Concave gasket / 8 * 22 * 2	4
7	DUPKC30-05A	Armrest aluminum pad	2
8	DUPGB/T12-1988	bolts M8X55	4
9	DUPGB/T9074.171994	Hexagon head combination bolts M6X16	6
10	DUPKC30A-04A	Belt cover	1
11	DUPKC30A-07A	Belt gear	1
12	DUPGB/T9074.17-1994	Hexagon head bolts M8X20	2
13	DUPKC42A-03A	chute assebmly	1
14	DUPKC55-24	Snow shovel	1
15	DUPKC55-15	Helical bracket washers	1
16	DUPKC26-11	Long washers	1
17	DUPKC26-14	Pinion gear	1
18	DUPKC26-12	Mandrel	1

# SNOWBLOWER ASSEMBLY

	<b>Part number</b>	<b>Part name</b>	<b>Quantity</b>
<b>19</b>	DUPKC26-15	Lower connection tube	1
<b>20</b>	DUPGB/T879.3-2000	Elastic cylindrical pin 3 * 18	2
<b>21</b>	DUPKC26-16	Rotating frame cover	1
<b>22</b>	DUPKC26-10A	Rotating frame	1
<b>23</b>	DUPGB/T12-1988	carriage bolt M8X16	3
<b>24</b>	DUPGB/T889.1-2000	hexagon lock nut M8	3
<b>25</b>	DUP4LXP900	belt	2
<b>26</b>	DUPKC30A-08	Belt cover gasket	2