

HSS1332TC

- All-new, track drive, 2 stage snowblower with improved Honda performance and durability
- 81.0 cm (31.9 in) clearing width / 51 cm (20 in.) clearing height
- Moves up to 65 metric tons of snow per hour with a discharge distance up to 17 metres (56 ft.)
- Residential or Commercial snow removal



SPECIFICATIONS

Axle Type	Track drive	Clearing Snow Volume Capacity *	Up to 65 metric tons (72 tons/hr)
Drive Type	Hydrostatic transmission (HST)	Engine Type	4-stroke, OHV, single cylinder
Transmission Oil Capacity	0.75 Litre (26.4 fl. Imp. oz)	Honda Engine Model	GX390T2
Recommended Oil	Honda hydrostatic transmission fluid	Displacement	389 cc (23.7 CID)
Speeds	Infinitely variable	Ignition System	CDI magneto
Maximum Ground Speed	Forward : 59.4 m/min. (194.9 ft./min) Reverse : 40.8 m/min. (133.9 ft./min)	Recoil Starter	Standard
Clearing Width	81.0 cm (31.9 in)	Electric Starter	N/A
Intake Housing Height	51.0 cm (20.1 in)	Lubrication System	Forced splash
Auger Diameter	35.5 cm (14.0 in)	Oil Capacity	1.1 Litre (38.7 fl. Imp. oz)
Auger Type	Steel serrated (Spiral)	Recommended Oil	SAE 5W30 API service classification SJ or later
Auger Drive	Belt driven shaft	Fuel Capacity	5.7 Litres (1.25 Imp. gal)
Auger Transmission	Screw gear	Recommended Fuel	Unleaded gasoline (Pump octane rating 86 or higher)
Auger Oil Capacity	0.16 Litre (5.6 fl. Imp. oz)	Operational Time per Tankful **	1.8 hours
Recommended Oil	SAE #90 gear oil	Wheel/Tire Size	N/A
Auger Height Adjustment	Gas assist	Overall Length	146.5 cm (57.7 in)
Chute Rotation	Remote manual crank	Overall Width	82.5 cm (32.5 in)
Chute Turning Radius	201°	Overall Height	112.5 cm (44.3 in)
Deflection Control	Remote manual lever	Dry Weight	120.0 kg (264.6 lb)
Chute Material	Steel	Lighting Coil	Standard
Maximum Throw Distance *	17 m (56 ft)	WorkLight	Standard
		Warranty	36-month, non-commercial use / 36-month, commercial use distributor's warranty

Models and/or colours may not be exactly as shown. Errors and omissions excepted. Specifications are subject to change without notice. See your Honda Power Equipment dealer for details.

For optimum performance and safety, please read your owner's manual before operating your Honda product. Always wear the appropriate safety gear when operating your Honda.

©TM — Trademarks of Honda Canada Inc. or used under licence from Honda Motor Co., Ltd. or third parties.