



- Chain drive. – Four blades per flange.
Available with square or curved blades. Shielded hexagonal side shaft.
- Transmission latérale à chaîne. – Quatre lames per flasque.
Lames équerrées ou hélicoidales. Déport sur arbre hexagonal. Protection de l'arbre hexagonal
- Trasmissione laterale a catena. – 4 zappette per flangia.
Zappette a squadra od elicoidali. Spostamento su albero esagonale. Protezione albero esagonale.
- Seitlicher Kettenantrieb. Messer mit 90° - Winkel oder schraubenförmig.
Verstellung auf 6-Kanten Welle. Schutz auf der Antriebswelle. 4-Fräsmesser/Flansch.
- Trasmision lateral a cadena: 4 cuchillas por plato. Cuchillas a escuadra o helicoidales:
desplazamiento sobre eje exagonal protegido.

MOD.								
	cm	inches	cm./inches	cm./inches		HP	Kg.	
RBS-2 100	100	40"	48	52	20-30	200	440	20
RBS-2 110	110	44"	48	62	20-30	208	458	24
RBS-2 120	120	48"	58	62	25-35	216	476	24
RBS-2 130	130	52"	58	72	25-35	228	502	28
RBS-2 140	140	56"	63	77	30-35	239	526	28
RBS-2 150	150	60"	63	82	30-45	252	555	32

rpm	rpm
540	208

Technical data are subject to change and not binding.



Printed in Italy

SOVEMA Srl
Via Olmo, 6 - 41013 GAGGIO DI PIANO (MO) ITALY
Ph. +39 059 93 85 85
Fx. +39 059 93 85 12
E-mail: sovema@sovema.com
Web-site: www.sovema.com

SOVEMA AGRITAL - CAB FACTORY
Via L. da Vinci, 20 - 24040 ARZAGO D'ADDA (BG) ITALY
Ph. +39 0363 87 833
Fx. +39 0363 87 355
E-mail: agrital@agrital.com
Web-site: www.agrital.com

SOVEMA Inc. U.S.A.
1937 Vanderhorn Drive - MEMPHIS, TN 38134
Ph. 901 388 8869
Fx. 901 388 8348
E-mail: sovema@sovemausa.com
Web-site: www.sovemausa.com

SOVEMA CANADA
4845 Portage Avenue - HEADINGLEY, MB R4H 1C7
Ph. 204 927 9042
Fx. 204 897 6975
E-mail: sovema@sovemacanada.com
Web-site: www.sovemacanada.com