


UGD814 - Excavator

*Ensure to park at the very front of the box with the bucket down when hauling a machine forward facing.



*Ensure to park at the very back of the box with the bucket down when hauling a machine rear facing.



The following list details whether the specified size of Excavator will fit the trailer orientation.

| Excavator Size | 17 | 26 | 35 | 50 |
|----------------|-----|-----|-----|-----|
| Forward Facing | Yes | Yes | Yes | No |
| Rear Facing | Yes | Yes | Yes | Yes |

UGD814SW

| | |
|--------------------------|-----------------------------|
| Dump Box Style: | Straight Wall |
| GVWR: | 17,500 lbs |
| Tare: | 6030 lbs |
| Payload Capacity | 11,470 lbs |
| Payload Center Dimension | 89.5" From Front of Deck |

DISCLAIMER: THIS DOCUMENT PROVIDES LOADING GUIDANCE TO ACHIEVE A PROPER DISTRIBUTION OF THE WEIGHT ON THE TRAILER. IT IS THE RESPONSIBILITY OF THE OPERATOR TO ENSURE THAT THE GVWR AND GAWR OF THE TRAILER, THE TOWING VEHICLE, AND THE COMBINATION OF VEHICLES IS NOT EXCEEDED.