



RZ-HD 48in Mower

Model No. RSZL1148FR730—Serial No. 400000000 and Up

Parts Catalog



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Main Frame Assembly 4

Frame with Decals Assembly No. 148-0997 6

Transmission Assembly 8

Body Styling Assembly 10

Fuel Tank Assembly..... 12

Seat Assembly 14

Motion Control and Parking Brake Assembly..... 16

Caster Tire Assembly..... 18

Drive Wheel Assembly 20

Electrical Assembly 22

Decklift Assembly..... 24


Engine Assembly 26

48 Inch Cutting Deck Assembly 28

Deck Decal Assembly No. 148-0975 30

Seat Suspension Assembly 32


Main Frame Assembly



Main Frame Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	148-0970-P11	1	Ztr Frame ASM	9	414-0002-00	10	8MM Push Type Retainer Nylon Black
1	148-0997	1	Frame ASM-Decals	10	148-1094	1	Decal-Warning
2	481-0005-00	1	Mwr Rubber Foot Rest Mat	11	148-1095	1	Decal-Warning
3	429-0002-00	2	Push-In Rubber Bumper Mwr Floor	12	127-0392	1	Decal-Hot Surface
4	439-0007-00-P11	1	Mwr Floorboard Paint	13	147-7364	1	Decal-Hitch
5	481-0006-00	1	Mwr Logo Floor Mat	14	126-4363	1	Decal-Warning
6	148-0233	1	ROPS	15	148-0466	1	Decal-Pump Belt Routing-Parker
7	413-0014-00	4	1/2-13 Hex Stover Locknut GR C Zinc	16	148-1191	1	Decal-Epa
8	418-0019-00	4	Bolt-HF				


Frame with Decals Assembly No. 148-0997



Frame with Decals Assembly No. 148-0997 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	148-0970-P11	1	Ztr Frame ASM	5	126-4363	1	Decal-Warning
2	148-1095	1	Decal-Warning	6	148-0466	1	Decal-Pump Belt Routing-Parker
3	127-0392	1	Decal-Hot Surface	7	148-1094	1	Decal-Warning
4	147-7364	1	Decal-Hitch				


Transmission Assembly



Transmission Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	148-0985-P11	1	Hydro Frame ASM	10	100-6116	8	Screw-HHF
2	450-0009-00	1	Hte10 Lt Side Hydrost Transm For Rz Hub	11	32128-49	8	Nut-HHF
3	450-0010-00	1	Hte10 Rt Side Hydrost Transm For Rz Hub	12	413-0027-00	4	Nut-HF, NI
4	419-0006-00	2	.312 ID X .875OD X .1875 THK F/W NYL	13	486-0030-00	1	No Plunger Limit Switch
5	439-0607-00-P11	1	Mwr Park Brake Brkt Lt Paint	14	418-0032-00	2	8-32 X 1/2 Ind. HWH Slot Type F Tcs Zinc
6	418-0008-00	2	Bolt-CARR	15	434-0003-00	1	Mwr Brake Pedal Release Spring
7	418-0010-00	2	Bolt-CARR	16	148-1262	4	Screw-CARR,Patch
8	439-0606-00-P11	1	Mwr Park Brake Brkt Rt Paint	17	413-1005-00	4	1/2-13 Hex Flange 2-Way Rev Cntr L/Nyz
9	439-0066-00-P11	1	Stand Trans Brake Interlock Brkt Paint	18	418-0045-00	4	3/8-16 X 1 Carriage Bolt Yz GR.8
				19	413-0029-00	4	Nut-Hex


Body Styling Assembly



Body Styling Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	148-0307	1	Console W/ Cupholder	16	418-0055-00	4	10-24 X 1/2 Socket C/S 18-8 SS
3	148-1097	1	Decal-Control Panel	17	419-0011-00	4	#10 Split Lockwasher 18-8 SS
4	148-0770	1	Tape-Foam	18	148-1172-P11	1	Muffler Guard [gray]
5	148-0801	1	Decal-Spartan, Front	19	439-0691-00-P11	1	2021 Rt/Srt Engr Cowling Rtpainted
6	148-0845	1	Decal-Tank	20	439-0692-00-P11	1	2021 Rt/Srt Engr Cowling Lt Painted
7	148-0870	1	Decal-Rz-HD Gt Trac Model	21	148-1042-05	1	Rt 45 Key Mnt
8	148-1056	2	Decal-Motion Control	24	148-0863	2	Decal-Model
9	148-1067-P11	1	Plate - Engine Cowling	25	780-2220-00	1	Cup Holder
10	148-1068-P12	1	Plate -Backer Plate	26	418-0008-00	4	Bolt-CARR
11	418-0054-00	4	Screw-HH	27	3253-4	4	Washer-Lock
12	413-0013-00	4	3/8-16 Nylon Insert Flange L/Nut Yz	28	419-0007-00	4	Washer-Flat
13	413-0023-00	2	1/4-20 Hex Flange Nut W/Serr Zinc	29	413-0022-00	4	Nut-HF
14	418-0018-00	4	3/8-16 X 4 Carriage Bolt Zinc	31	418-0049-00	2	Bolt-HWH
15	418-0031-00	2	1/4-20 X 1/2 Carriage Bolt,Yz				


Fuel Tank Assembly



Fuel Tank Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	418-0054-00	2	Screw-HH	10	418-0045-00	2	3/8-16 X 1 Carriage Bolt Yz
2	429-0002-00	2	Push-In Rubber Bumper				GR.8
			Mwr Floor	11	3253-4	3	Washer-Lock
3	148-0478-P11	1	Bracket-Tank Support	12	419-0007-00	4	Washer-Flat
5	467-0001-00	1	Mwr Gasoline Fuel Tank	13	413-0020-00	2	3/8-16 Hex Flange Nut
			Assy				W/Serr Zinc Yellow
7	481-0004-00	1	Rubber Tank Storage	14	418-0108-00	1	Screw-HH
			Compartment Insert	15	418-0287-00	1	Screw-Shoulder,HHF
8	148-0844	1	Decal-Tank	16	434-0020-00	1	Spring-Compression


Seat Assembly



Seat Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	3256-24	1	Washer-Plain	12	413-0027-00	1	Nut-HF, NI
2	148-1047	1	Non 360 Seat Base Plate	13	114-4681	1	Screw-HHF
			Safty Decal ASM-	14	107-0075	1	Bushing-Latch, Seat
3	471-0035-00	1	Rt Pro Seat	15	148-0953	1	Bracket-Latch
4	410-0010-00	2	1/2In ID X 5/8In OD X 1/2In	17	126-8923	1	Spring-Torsion, Latch
			Flange Bush	18	419-0006-00	1	.312 ID X .875OD X .1875
5	418-0038-00	2	1/2 X 1/2 Socket Shoulder				THK F/W NYL
			Bolt Zc Yellow	19	116-7230	3	Screw-HHF
6	439-0065-00-P11	1	Mwr Seat Latch Hook Paint	20	426-0241-00-P11	1	2020 Rt/Srt Univ Float Seat
7	413-0022-00	4	Nut-HF				Cvr PLT
8	413-0029-00	3	Nut-Hex	21	484-0002-00	1	Stand Up Mwr Brake Arm
9	413-0019-00	4	5/16-18 Nylon Insert Flange				Grip
			L/Nut Zc	22	125-8473	1	Decal-Warning, Battery
10	322-47	1	Screw-HH	23	486-0036-00	1	Mwr Seat Switch
11	413-0016-00	1	.312Idx.625Odx.062 THK				
			Thrust Brg Oi Brz				


Motion Control and Parking Brake Assembly



Motion Control and Parking Brake Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	148-0888-05	1	LH Pivot ASM	31	486-0030-00	2	No Plunger Limit Switch
2	148-0889-05	1	RH Pivot ASM	32	418-0032-00	4	8-32 X 1/2 Ind. HWH Slot Type F Tcs Zinc
3	148-0886	4	Bushing-Flange	33	439-0009-00-P11	1	Mwr Frame Brake Mtg Brkt Paint
4	148-0897	4	Bushing-Flange	34	410-0009-00	1	1/2In ID X 3/4In OD X 3/8In Flange Bush
5	148-0885	2	Sleeve-Pivot	35	490-0016-00-P11	1	Mwr Brake Lock Lever Assy Painted
6	109-5575	2	Spring-Leaf	36	139-2631	1	Screw-HH
7	419-0003-00	2	1/2 Fender Washer 1-1/4In OD Zinc	37	413-0002-00	1	Nut-Lock
8	418-0050-00	2	1/2-13 X 3 Hex C/S GR 5 Zinc W/Loctite	38	418-0027-00	3	Bolt-HH
9	431-0001-00	2	Height Adjustable Control Arm	39	435-0004-00	1	Mwr Brake Linkage
10	403-0020-10-P11	2	Mower Drive Handle Tube Abc	40	3272-11	1	Pin-Cotter
11	484-0001-00	2	Control Arm Handle Grip	41	413-0052-00	1	3/8 ID X 3/4 OD X .125 THK Bronze Washer
12	116-7230	4	Screw-HHF	42	490-0017-00-P11	1	Mwr Brake Unlock Lever Assy Painted
13	323-20	2	Screw-HH	43	413-0012-00	4	1/4-20 Hex Flange Nut
14	419-0007-00	2	Washer-Flat	44	418-0029-00	2	1/4-20 X 1-1/4 Hex C/S GR 2 Zinc
15	148-1012	4	Washer-Belleville	45	323-7	1	Screw-HH
16	413-0013-00	3	3/8-16 Nylon Insert Flange L/Nut Yz	46	418-0010-00	3	Bolt-CARR
17	418-0054-00	2	Screw-HH	47	413-0020-00	2	3/8-16 Hex Flange Nut W/Serr Zinc Yellow
18	413-0027-00	6	Nut-HF, NI	48	434-0015-00	1	2020 Mwr Brake Pedal Tension Spring
19	410-0070-00	2	5/16-24 Spher Rod End Zinc LH Thd Fem	49	434-0003-00	1	Mwr Brake Pedal Release Spring
20	AU426-516	2	Screw-HH	50	148-0911-P11	1	ASM, Gt-Trac [gray]
21	435-0033-00	2	1310 Ttq Drive Arm Rod	51	429-0002-00	2	Push-In Rubber Bumper Mwr Floor
22	410-0071-00	2	5/16-24 Spher Rod End Zinc RH Thd Fem	52	618-2023-00	4	Screw-CARR
23	3220-20	2	Nut-Jam	53	413-0029-00	4	Nut-Hex
24	09207	2	Nut	56	240-6	1	Grommet-Rubber
25	322-47	4	Screw-HH	57	418-0048-00	2	5/16-18 X 3/4 Hex Flange Bolt GR 8 Yz
26	413-0022-00	15	Nut-HF				
27	487-0005-00	4	5/16-18X1.286 Damper Ball Stud (.562 TI)				
28	487-0001-00	2	Control Arm Damper				
29	613-0065-00	2	Standoff-Hex				
30	3234-28	2	Screw-HHF				


Caster Tire Assembly



Caster Tire Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	413-0002-00	2	Nut-Lock	9	419-0025-00	2	Ft Hub Plastic Washer
2	103-3540	4	Bearing-Ball	10	422-0027-00	2	Rz/Rt Pro Ft Tire Assy-Smooth Tread
3	410-0018-00	4	Rz Ft Wheel Bearing	11	425-0010-00	2	Mwr Ft Wheel Spanner
4	413-0063-00	2	Nut-Hex	12	425-0011-00	2	Caster Fork Shaft Bearing Spacer
5	418-0002-00	2	1/2-20 X 1-1/4 Hex Flange Bolt GR 8 Yz	13	426-0006-00-P11	2	Mwr Caster Shaft Washer
6	325-24	2	Screw-HH	14	437-0019-00	2	Mwr Caster Shaft
7	419-0003-00	2	1/2 Fender Washer 1-1/4In OD Zinc	15	490-0046-00-P11	2	Rz Caster Fork ASM
8	419-0024-00	2	1In L/W Med Split Zc				


Drive Wheel Assembly



Drive Wheel Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	161-9726	2	Wheel And Tire ASM	1:3	232-27	1	Stem-Valve
1:1	140-7969	1	Wheel	2	413-0015-00	8	1/2-20 Lugnut
1:2	161-9727	1	Tire				


Electrical Assembly



Electrical Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	439-0008-00-P11	1	Mwr Battery Box	14	321-4	2	Screw-HH
2	468-1004-00	1	12 Volt Start Battery 300CCA	15	104-7201	2	Nut-HF, NI
3	418-0034-00	2	1/4-20 X 7 Carriage Bolt Zinc	16	32180-030	1	Clip-Tie
4	443-0001-00	1	Battery Hold Down	18	486-0060-00	1	PTO Switch
5	3231-6	2	Screw-CARR	19	486-0062-00	1	Ignition Switch
6	413-0020-00	2	3/8-16 Hex Flange Nut W/Serr Zinc Yellow	20	486-0065-00	1	2023 Mwr Key
7	515-0038	2	Washer-Flat	21	436-0002-00	1	3.15 Lgth Straight Insul Term Cover Red
8	1-803038	2	Wingnut	22	436-0003-00	1	Straight Insulating Terminal Cover
9	486-0006-00	1	Heavy Duty Start Solenoid	23	120-9551	4	Screw-HWH
10	486-0017-00	1	Mwr Negative Cable 28	24	3290-379	5	Tie-Cable
11	486-0018-00	1	Mwr Start Wire 12	25	148-0824	1	Harness-Wire
12	677-2075-00	1	12 Volt Auxilliary Plug	26	148-1063	1	Hour Meter
13	486-0016-00	1	Mwr Positive Battery Cable 25In				


Decklift Assembly



Decklift Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	148-0095	1	1/2-13X1.25In Hex Flange Bolt (GR.8) Yz	22	32128-49	1	Nut-HHF
2	148-1074	1	Decklift ASM-Front	23	618-2068-00	1	3/8 X 3/4In GR 8 CARR Bolt Zinc
3	148-1085	2	Support-Bearing Housing	24	148-0422	1	Hex Coupling Nut - Reducer (3/8" To 5/16
4	109-9410	2	Bearing-Cross Shaft, Front	25	419-0007-00	1	Washer-Flat
5	135-5694	2	Bushing-Flange	26	487-0008-00	1	5/16-18X1.286 Damper Ball Stud (.562 TI)
6	135-9063	2	Bushing-Flange	27	487-0005-00	1	5/16-18X1.286 Damper Ball Stud (.562 TI)
7	148-1003-P11	1	(Rz Rear HOC Hanger)	28	148-0951	1	Pedal
8	148-0418-P11	1	Arm-Decklift Rear (3/8")	29	418-0042-00	1	1/2-13 X 3-1/2 Hex C/S GR 5 Zinc Yellow
9	148-0950-P11	1	Lever-Lift	30	148-1036	1	Decal-Height Of Cut
10	148-1075-P11	1	Plate-Decklift, Arm LH [gray]	31	923786	4	Rivet
11	148-0940-P11	1	Link-HOC(Left Side)	32	434-0008-00	1	Rz Deck Assist Gas Spring
12	148-0941-P11	1	Link ASM-HOC(Right Side Welded)	33	148-1080	4	Screw-CARR
13	148-0946-P11	1	Bracket-HOC ASM [gray]	34	148-1087	6	Screw-HHF
14	148-0943	1	Plate-Transport Lock	35	413-0029-00	8	Nut-Hex
15	148-0949-P11	1	Cover-HOC	36	618-2023-00	2	Screw-CARR
16	420-0009-00	1	Magnetic Pin For Stand On Mwr	37	413-0022-00	2	Nut-HF
17	410-0009-00	4	1/2In ID X 3/4In OD X 3/8In Flange Bush	38	418-0083-00	1	3/8 X 1/2 Socket Shoulder Bolt Yz
18	100-6116	4	Screw-HHF	39	148-1211	1	Bushing-Flange
19	413-1005-00	10	1/2-13 Hex Flange 2-Way Rev Cntr L/Nyz	40	148-1212	1	Washer-Plain
20	418-0276-00	1	Rr Deck Height Bolt (Machined)	41	484-0002-00	1	Stand Up Mwr Brake Arm Grip
21	3296-45	1	Nut-Hex				


Engine Assembly



Engine Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	415-0003-00	1	Kawasaki Fr730V-Ds27-R Engr	21	461-0004-00	1	Mwr Pump Belt Rt A X 68.25In Eff Lngth
2	418-0023-00	4	3/8-16 X 1-1/8 Ind HWH W/Serr Tri Lob Zy	22	418-0013-00	1	Bolt-HH
3	415-0074-00	1	2019 Exhaust Syst For Kawi Fr Fs And Ft	23	32128-37	2	Nut-HF
4	104-2612	4	Nut-HF	24	434-0007-00	1	Mwr Deck Spring
5	439-0244-00-05	1	Mwr Pump Idler Tensioning Brkt Black	25	418-0278-00	1	M8-1.25 X 20MM Hex Flange Bolt Zinc 10.9
6	439-0493-00-05	1	2021 Ttq Mower Ogura Clutch Bracket	26	425-0006-00	1	Mwr Inner Idler Spacer
7	410-0007-00	2	3/4In ID X15/16In OD X 1-1/8In Flng Bush	27	424-0002-00	1	1/4In Drive Type Grease Fitting Yz
8	490-0018-00-05	1	Mwr Pump Idler Assy Black	28	419-0001-00	1	1/2In X 1-5/8 Belleville Cup Washer Yz
9	418-0009-00	1	1/2-13 X 5-1/2 Hex Flange Bolt GR 8 Zy	29	418-0223-00	1	Ttq Clutch Bolt
10	418-0008-00	2	Bolt-CARR	30	3253-6	1	Washer-Lock
11	418-0062-00	2	5/16-18 X 1-1/4 Carriage Bolt Zc/Yel	31	413-0012-00	1	1/4-20 Hex Flange Nut
12	413-0002-00	1	Nut-Lock	32	451-0002-00	10	Mwr Fuel Tank Black 3/16In Vent Tube 1Ft
13	433-0013-00	1	5-3/4In Idler Pulley 7/16In Spacer Assy	33	751-1014-00	10	1/4In SAE J30R7 Bulk Hose 1Ft
14	325-9	1	Screw-HH	34	3290-379	4	Tie-Cable
15	32128-49	3	Nut-HHF	35	472-0004-00	3	1/2In (#8) Hose Clamp
16	413-0022-00	6	Nut-HF	36	418-0280-00	1	5/16-18 X 3/8 Socket Set Screw
17	430-0001-00	1	Mwr Pump Idler Spring Tensioner	37	3-6781	1	Washer-Flat
18	433-0001-00	1	Mwr Hydraulic Pump Drive Pulley (A Belt)	38	464-0001-00	1	Mwr Throttle Cable Assy W / Handle
19	1-807259	1	Key	39	464-0002-00	1	Mwr Choke Cable Assm
20	470-0004-00	1	Mwr Ttq Ogura Clutch	40	418-0055-00	2	10-24 X 1/2 Socket C/S 18-8 SS
				41	110-3145	2	Nut-Lock


48 Inch Cutting Deck Assembly



48 Inch Cutting Deck Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	148-0975	1	ASM- 48" Deck W/Decals	32	413-0027-00	9	Nut-HF, NI
2	148-0002	3	Spindle ASM 5In Deck	33	148-0839-P11	1	Bracket- Idler Damper
2:2	116-4004	2	Bearing	34	434-0009-00	1	Idler Gas Spring
2:3	148-0025	1	Spacer, Bearing	35	322-47	2	Screw-HH
2:4	116-3473	6	Bolt-Round Head	36	413-0016-00	1	.312Idx.625Odx.062 THK Thrust Brg Oi Brz
3	422-0061-00	4	Mwr Anti-Scalp Whl W/O Grease Fitting	37	3232-1	1	Screw-CARR
4	418-0016-00	2	Screw-HH	38	418-0246-00	2	1/2-13 X 2-3/4 Hex Flange Bolt (GR.8) Yz
5	418-0015-00	1	1/2-13 X 8-1/2 Hex C/S GR 2 Zinc Yellow	39	434-0007-00	1	Mwr Deck Spring
6	413-0002-00	7	Nut-Lock	40	490-0047-00-05	2	Rz Mwr Deck Stablzr Assy
7	148-0105	3	Shaft - Spindle	41	732-2000-00	8	Red A80 Susp Bushing
8	148-0102	3	Guard-Bearing Top 0.673In	42	418-0021-00	4	1/2-13 X 3-3/4 Hex C/S (GR.5) Zc/Yel
9	148-0029	3	Pulley	43	732-2001-00	4	UTV A-Arm Bushing Sleeve
10	148-0114	6	M16 Spring Washer (39Mmod/ 3.9MM THK)	44	9264964	3	Screw-HWH, Thread Cut
11	148-0112	3	M16X1.5 C8.8 Hex Nut	45	435-0013-00-P11	4	Rz Mwr Deck Actuator Conn Link Paint
12	148-0101	3	Blade-Rotary	46	148-0999-00-P11	1	Bracket-Chute
13	148-0108	3	Washer-Hex	47	148-0836-P11	1	Deck Chute Hinge ASM
14	429-0001-00	1	Mwr Nylon Deck Guard	48	481-0010-00	1	Rz Mwr Rubber Discharge Chute
15	148-0094	4	Pin-Belt Cover	49	439-0431-00-05	1	Mwr Deck Chute Hinge Backer Brkt
16	433-0015-00	2	6-3/4In Idler Pulley 15/16In Spacer Assy	50	148-0109	3	M16X1.5-30MM C10.9 Hex Bolt
17	148-0092	2	Cover Belt	51	148-0234	4	Nut-Knob
18	418-0110-00	1	.767Idx1.125Odx.016 THK Trip Wv Washer	52	419-0010-00	8	.443 ID X .749 OD X .125 THK Nylon Black
19	410-0007-00	2	3/4In ID X15/16In OD X 1-1/8In Flng Bush	53	324-8	8	Screw-HH
20	490-0019-00-P11	1	Mwr Deck Idler Pulley Arm Assy Paint	54	424-0002-00	1	1/4In Drive Type Grease Fitting Yz
21	418-0009-00	3	1/2-13 X 5-1/2 Hex Flange Bolt GR 8 Zy	55	425-0006-00	1	Mwr Inner Idler Spacer
22	433-0014-00	1	6-3/4In Idler Pulley 7/16In Spacer ASM	56	418-0060-00	7	5/16-18 X 1 Carriage Bolt GR 8 Yz
23	325-9	1	Screw-HH	57	419-0006-00	2	.312 ID X .875OD X .1875 THK F/W NYL
24	439-0257-00-P11	1	Deck Idler Pulley Belt Retnr Brkt Paint	58	413-0029-00	18	Nut-Hex
25	32128-49	7	Nut-HHF	59	3253-4	4	Washer-Lock
26	324-7	2	Screw-HH	60	116-7230	4	Screw-HHF
27	148-1137	1	Bolt-L	61	107-8541-05	1	Baffle-Discharge
28	413-0020-00	2	3/8-16 Hex Flange Nut W/Serr Zinc Yellow	62	3231-27	2	Screw-CARR
29	418-0010-00	2	Bolt-CARR	63	104-8301	2	Nut-HF, NI
30	413-0022-00	2	Nut-HF	64	139-6342	1	Belt-V
31	32128-37	21	Nut-HF	65	3296-23	1	Nut-Lock, NI

Deck Decal Assembly No. 148-0975




Deck Decal Assembly No. 148-0975 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1		1	Deck ASM-48, ●	4	148-0430	1	Decal-Safety Blade Torque
2	125-6127	2	Decal-Rotating Fan Hazard	5	148-0869	1	Decal-Deck, 48-Xft
3	132-0872	1	Decal-Danger, Deck	6	148-0260	1	Decal-Deck Belt Routing

● Not serviced separately

Seat Suspension Assembly



Seat Suspension Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	104-7201	2	Nut-HF, NI	3	487-0004-00	2	Seat Rr Susp Elastomer
2	418-0039-00	2	1/4-20 X 1 Button Socket C/S 18-8 SS	4	515-0038	2	Washer-Flat

Notes:

Notes:

