



Service Part List_CSX3000_Version A

No.	Product Model#	Part Number	Description	Qty
1	CSX3000	4870752001	Switch Assembly	1
2	CSX3000	3660697001	Torsion Spring	1
3	CSX3000	2827132002	Switch Lever Assembly	1
4	CSX3000	3422689001	Trigger Lever	1
5	CSX3000	2830718001	Fuse Electric Assembly	1
6	CSX3000	5620479001	Screw	23
7	CSX3000	3521234001	Plunge Frame	1
8	CSX3000	3130880001	Lock Button	1
9	CSX3000	3707341001	Chip Shield	1
10	CSX3000	3707012001	Wood Teeth	1
11	CSX3000	5620013006	Hexagon Socket Screw	6
12	CSX3000	3707340001	Protecting Cover Plate	2
13	CSX3000	5660028001	E Ring	1
14	CSX3000	3422529001	Sprocket	1
15	CSX3000	5660208002	Gasket	1
16	CSX3000	5690474001	Felt Ring	1
17	CSX3000	5650526002	Plain Washer	1
18	CSX3000	3130983001	Rear Tube	1
19	CSX3000	2827231001	Pump Assembly	1
20	CSX3000	3570062001	Worm	1
21	CSX3000	3130982001	Intermediate Tube	1
22	CSX3000	5610291003	Tapping Screw	6
23	CSX3000	5620019005	Hexagon Socket Screw	3
24	CSX3000	2730321001	DC Motor	1
25	CSX3000	2830736002	Control Electric Assembly	1
26	CSX3000	2830698001	Signal Acquisition PCBA	1
27	CSX3000	5610237001	Tapping Screw	6
28	CSX3000	4860525003	Internal Wire ASSY	1
29	CSX3000	3131120001	Rubber Ring	1
32	CSX3000	2827286002	Oil Screen Assembly	1
33	CSX3000	3131184001	Sheath	1
34	CSX3000	5680272001	Socket Wrench	1
35	CSX3000	2827131002	Brake Assembly	1
201	CSX3000	2827709001	Kettle Assembly	1
30	CSX3000	2827277002	Kettle Cover Assembly	1
31	CSX3000	3128576001	Valve	1